



Installation and Maintenance Instructions for IFC Triple Duty Valves

Installation and Maintenance Instructions for IFC Triple Duty Valves

IFC MODEL TD125FIBE – TRIPLE DUTY VALVE

The IFC Model # TD125FIBE Triple Duty Valve combines a calibrated balancing valve, a shut-off valve, and a center guided silent check valve into a single unit.

INSTALLATION

Determine the system flow requirements. Refer to pressure drop charts and select a valve whose 50% flow rate is closest to this figure. (NOTE: The valve size may not be the same as the line size).

Install valve, flow arrow in direction of flow, 5-10 pipe diameters from the discharge of the pump. System operating conditions are not to exceed operating conditions of 175 psig @ 250 degrees F.

OPERATION

1. Turn handwheel counter clockwise until indicator reads in the 100% open position.
2. Start system pump, and purge all air from system.
3. Install test plugs or pressure gauges in the two ports on the inlet and outlet of the TD125FIBE valve and read the differential pressure across the valve. Pressure drop across the valve should not exceed 11 psi. Excessive noise or damage to the valve may occur on pressure drop above 11 psi.
4. Refer to the appropriate performance curve or Cv rating table to determine flow based on the results from step “3” and the “percent open” as indicated.
5. Slow close the valve, turning handwheel clockwise, until the specified GPM flow rate is achieved. Secure or remove handwheel to maintain this setting.
6. Consult pump manufacturers guidelines if specified GPM is achieved with the valve at < 50% open, pump impeller may need to be trimmed.

MAINTENANCE

The IFC Model # TD125FIBE requires no regular maintenance. Replacement parts are available. Contact IFC or your nearest representative. Prior to closing the valve be sure to note % open location and return to this position.